




SB7-CW3465

Spring return

Flush pushbutton with lamp LED

push to lock
push to release



- Green/PG SB7-CW3365
- Yellow SB7-CW3565
- Pure Blue SB7-CW3665
- Red SB7-CW3465
- Green/PG SB7-CWL3365
- Yellow SB7-CWL3565
- Red SB7-CWL3465

